Medical Ultrasound

October 3, 2022 Center for Fast Ultrasound Technical University of Denmark Nathalie Sarup Panduro, medical doctor, PhD student

Agenda

- Medical specialities and ultrasound
- Scan planes
- What can we see?
- Artefacts in ultrasound
- Scanning organs
- Procedures and conventions
- Scanning session

Medical Specialities and ultrasound

Which specialities use ultrasound?


Nearly all specialities

Medical Specialities and ultrasound

Speciality		Speciality	
Anesthesiology	Guide for local injections, catheters	Obstetrics/ Gynecology	Pregnancy Transvaginal US
Cardiology	Echocardiography		
Emergency medicine	Point of care ultrasound / FAST	Nephrology / Urology	Urogenital system
		Rheumatology /	Muscles, tendons
Gastroenterology / Gastro surgery	Abdominal organs Endoanal US Intraoperative US	Orthopedic surgery	Ligaments, joints Nerves
		Pulmonology	EBUS
Head and Neck Surgery	Thyroid, Parathyroid Lymph nodes	Radiology	Contrast-enhanced US (CEUS)
Cardiovascular	Thrombosis/stenosis		88 (8288)
surgery	diagnostics	Radiology	Interventional US
Neurology	Carotid arteries Transcranial US	Radiology	Image-fusion

Scan planes

- Transverse/axial/horizontal plane
- Sagittal/vertical plane
- Frontal/coronal plane



Scan planes

Axial/transverse

Sagittal

Coronal









Images from imaios.com

Transverse/axial plane




Illustrations from radiologykey.com

Transverse/axial plane




Illustrations from radiologykey.com

Sagittal plane




Coronal plane




In medical ultrasound, it is possible to differentiate tissues/structures from each other due to differences in densities and in the speed of sound through tissues or structures.

Air and bony structures reflect and/or absorb the ultrasound waves completely with the closest edge appearing echo-rich (bright) and (almost) no image behind.





- Reflection occurs due to the differences in acoustic impedance (resistance) at the interface between tissues
- Total reflection between tissue and air/bone
- Absorption occurs when the tissue/medium reduces the intensity of an ultrasound wave as it passes through it



 Solid organs and other soft tissues appear in different shades of grey depending on their individual impedance mismatches


 Fluids (e.g. cysts, urine, blood, ascites, gall) are "echo empty" and appear black / dark grey = anechoic








• Usually, artefacts are used as a systematic technological failure in the medical language and perceived negatively.



l as a systematic technological failure nd perceived negatively.

Case courtesy of Dr David Cuete, Radiopaedia.org, rID: 25637



as a systematic technological failure I perceived negatively.

Case courtesy of Dr Chris O'Donnell, Radiopaedia.org, rID: 51842

- Usually, artefacts are used as a systematic technological failure in the medical language and perceived negatively.
- In ultrasound, diagnostic artefacts can be <u>used constructively</u> and they can draw our attention to pathology.


Artefacts: Enhancement

• Homogenous watery fluids allow sound to pass through more easily due to low attenuation/no reflection.

 \rightarrow only a minimal amount of sound is absorbed, and the region behind the fluid will receive more sound than the surrounding tissue. Therefore, the area will appear brighter.

This effect is called acoustic enhancement.

Artefacts: Enhancement







Artefacts: Shadowing

 Band of markedly reduced echogenicity behind strong reflectors (bone, air)

Artefacts: Shadowing






Artefacts: Edge shadowing

- Occur at the edges of round cavities whose walls lie tangentially to the sound beam.
- Result of the refraction of the ultrasound beam along the edge of the structure.
- This limits the penetration depth and will appear as edge shadowing.

Artefacts: Edge shadowing

 Sound of for e prostat curved

> This lir shado




https://www.pocus101.com/basic-principles-of-ultrasound-physics-and-artifacts-made-easy/

Artefacts: Reverberation

- Reverberation artefacts occur when ultrasound waves bounce between two reflective structures. The reflected sound waves will return with a delay.
- The delay is evaluated as increased penetration depth and the echoes are visualized as multiple copies of the structure too far down on the image


Artefacts: Reverberation



es bounce Id waves

th and the ture too far


Artefacts: Reverberation




Artefacts: Mirror image artefact

- This artefact occurs when there is a highly reflective surface (e.g. the diaphragm) in the path of the ultrasound beam.
- The sound waves are deflected laterally by the diaphragm, encounter a reflector, are reflected back to the diaphragm and returned to the probe.
- The mirror image artefact will mimic an object similar to the true object at the opposite side of the tissue.

Artefacts: Mirror image artefact



Artefacts: Mirror image artefact



Case courtesy of Dr Ayush Goel, Radiopaedia.org, rID: 26560

Scanning solid organs: Liver

Upper middle abdominal: left liver lobe

Subcostal: right liver lobe, vena cava inferior, portal veins, gallbladder.

Intercostal position right flank: right liver lobe, portal veins, liver veins

Scanning solid organs: Liver LIVER TRANS S-I 32fps 12cm 🎿 🔤 🗲 Fr293 Biorender.org Case courtesy of Dr Henry Knipe, Radiopaedia.org, rID: 38664


Scanning solid organs: Liver



Scanning solid organs: Liver





Scanning solid organs: Liver



Subcostal ("liver window") or right flank scanning: right kidney


Left flank scanning: left kidney













Case courtesy of Dr Balint Botz, Radiopaedia.org, rID: 59788

Scanning solid organs: Spleen

Intercostal scanning rear axillary line: spleen with the same structure as the liver

Subcostal scanning: thin people


Scanning solid organs: Spleen

Biorender.org



https://radiologykey.com/ultrasound-of-the-spleen-and-lymphatic-system/

Scanning solid organs: Spleen




Case courtesy of Dr Ian Bickle, Radiopaedia.org, rID: 52825


Scanning solid organs: Bladder

Transabdominal scanning: bladder (full)

Scanning solid organs: Bladder



Scanning solid organs: Bladder



Procedures and conventions


- Dim light in the room
- The examiner on the right side of the patient
- Transducer in the right hand
- Grab as if you are holding tweezers or a pen
- Identify left / right or up / down on the transducer (NB! Indicator on transducer head)
- Use plenty amounts of gel
- Support the forearm and hand on the person you are scanning
- View the screen and not the person you are scanning
- Optimize image according to target



Procedures and conventions

Moving the transducer

- Parallel shift (or sliding)
- Rotation 90 degrees
- Rocking (from side to side)
- Tilting (back and forth)
- Compression



Scanning solid organs

Let's try